


Configuration du Netgear:

Afin de pouvoir faire communiquer tous les systèmes, il faut configurer le netgear en changeant son adresse ip. Par défaut l'adresse ip du routeur est 192.168.0.239, il faut donc se mettre sur une même adresse ip, puis le taper sur la barre de recherche d'un navigateur. On tombe alors sur une page de



Une fois connecté, il suffit de se rendre dans l'onglet "Ip configuration" et d'y changer les paramètres. (Ne pas oublier après changement d'ip de se mettre sur la même plage d'ip que le switch.)

The screenshot shows the Netgear GS108T web interface in a browser window. The address bar shows the URL `http://192.168.2.2/base/web_main.html`. The page title is "NETGEAR GS108T 8 Port Gigabit Smart Switch". The navigation menu includes "System", "Switching", "QoS", "Security", "Monitoring", "Maintenance", and "Help". The "System" menu is expanded, showing "Management", "Device View", "SNMP", "LLDP", and "Services". The "IP Configuration" page is displayed, showing the "IP Configuration" section with three radio buttons: "Dynamic IP Address (DHCP)", "Dynamic IP Address (BOOTP)", and "Static IP Address" (selected). The "Static IP Address" section has three input fields: "IP Address" (192.168.2.2), "Subnet Mask" (255.255.255.0), and "Default Gateway" (192.168.2.254). Below this is the "Management VLAN" section with a "Management VLAN ID" input field (1) and a range "(1-4093)". At the bottom right are "CANCEL" and "APPLY" buttons. The footer shows "Copyright © 1996-2018 NETGEAR ®".

NETGEAR
Connect with Innovation™

GS108T
8 Port Gigabit Smart Switch

System Switching QoS Security Monitoring Maintenance Help LOGOUT

Management Device View SNMP LLDP Services

System Information
IP Configuration
IPv6 Network Configuration
IPv6 Network Neighbor
Time
Denial of Service
DNS
Green Ethernet

IP Configuration

IP Configuration

☐ Dynamic IP Address (DHCP)
☐ Dynamic IP Address (BOOTP)
☒ Static IP Address

IP Address: 192.168.2.2
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.2.254

Management VLAN

Management VLAN ID: 1 (1-4093)

CANCEL APPLY

Copyright © 1996-2018 NETGEAR ®